


Main power - White cable
Motor cable - Black cable



The BLACK and BROWN wires coming from the motor are directional wires, so may need to be swapped over if the operational direction is incorrect. (i.e up button taking the door down & vice versa)